

SHADYS Ray Club Car Precedent Install Instructions

Your SHADYS Ray golf car shade is quick and easy to install following our step by step instructions. Please contact your local golf car dealer or Shadys with questions.

Step 1 Clean inside edge of canopy with alcohol wipe and allow to dry. Apply primer to inside edges where Shadys will be attached and allow to dry for 5 minutes.



Step 2
Find inside center of canopy.



Step 3
Beginning at center, adhere Velcro strip along inside edge.



Step 4
Logo facing out, attach Shadys at center of canopy and press firmly along inside edge.



Step 5
Lift seat, attach Velcro pad to smooth area along inside panel. Attach strap to Velcro pad and lower seat.

Note: DO NOT ATTACH IN RAIN OR DAMP CONDITIONS.

